saro
Gastro-Products

Operating Manual

Soap Dispenser Model SPM

Item-No.: 298-1040



English - Translation

TABLE OF CONTENTS

SCOPE OF DELIVERY 3
TECHNICAL OVERVIEW 4
SYMBOL EXPLANATIONS 5
GENERAL INSTRUCTIONS 6
SAFETY INSTRUCTIONS 7
DEVICE INSTALLATION 8
STRUCTURE AND COMPONENTS 9
INITIAL START-UP 9
CLEANING 10
TAKING DEVICE OUT OF OPERATION / STORAGE / TRANSPORT 10
TROUBLESHOOTING 11
EXPLODED VIEW 12
EXPLODED VIEW: LEGEND 13
PACKAGING DISPOSAL 14
DEVICE DISPOSAL 14

Dear Customer,

Congratulations on your new SARO soap dispenser.

The product you have purchased has been designed for use in commercial environments such as restaurants, hotels, cafés, canteens, and sanitary facilities.
It is intended for the hygienic and economical dispensing of liquid soap or disinfectant.
The soap dispenser is particularly suitable for washrooms with high visitor frequency to ensure cleanliness and hygiene reliably.

Please read the operating instructions carefully before putting the unit into operation.

We wish you much satisfaction with your new SARO product.

SCOPE OF DELIVERY

- 1 Soap dispenser
- 1 operating manual
- 2x Screws ST4.2x20
- 2x Plastic plugs Ø 6 mm
- 1 Key

TECHNICAL OVERVIEW

Seifenspender	
Model	SPM
Order No.	298-1040
Material	Stainlesss steel
Lock	Lockable
Spendesystem	Manual push-button-system
Füllstandsanzeige	Yes
Mechanismus	Drip-stop pump mechanism
Kapazität	1,8 liters
Ausgabe pro Hub	0,001 liters
Dimensions	W 140 x D 120 x H 120 mm
Net/Gross weight	1 kg / 1,2 kg
GTIN [EAN-Code]	4017337298167

SYMBOL EXPLANATIONS



WARNUNG!
Dieses Symbol kennzeichnet Gefahren, die zu Verletzungen führen können. Halten Sie die angegebenen Hinweise zur Arbeitssicherheit unbedingt genau ein und verhalten Sie sich in diesen Fällen besonders vorsichtig.

WARNING!
This symbol indicates hazards that may cause injuries. Always follow the specified safety instructions precisely and exercise extra caution in these situations.

GENERAL INSTRUCTIONS

- Keep this operating manual readily accessible near the device.
- The manufacturer/supplier cannot be held responsible for any damage resulting from failure to follow these operating instructions.
- If these operating instructions are not observed, the safety of the device can no longer be guaranteed.
- When passing the device on to third parties, this manual must be included.
- After unpacking the device, make sure that everything is in perfect condition. If you discover any damage, do not connect the device and contact your dealer immediately.
- Check that all components listed in the scope of delivery are present. If anything is missing, contact your dealer.
- Keep the device's packaging. Only in the **original packaging** can the device be transported safely (e.g. for repair purposes or when moving).
- Please note that all packaging materials (plastic bags, cardboard, Styrofoam parts, etc.) can pose a danger to children and must therefore not be stored near them.
- If it is not possible to keep the packaging, separate the different materials and take them to the nearest collection point for proper disposal.
- For hygienic reasons, daily cleaning is recommended during use.
- The manufacturer/supplier cannot be held responsible for any damage resulting from failure to follow these instructions. In such cases, the safety of the device can no longer be guaranteed.


SAFETY INSTRUCTIONS

- Improper operation and incorrect handling may cause malfunctions of the device and injuries to the user.
- The device is neither suitable nor intended for the storage of medicines or easily flammable, combustible, or explosive substances.
- Observe the accident prevention regulations and general safety provisions applicable to the area of use.
- Do not place heavy objects, loads, or liquids on the device.
- A damaged device must **not** be used!
- Repairs must be carried out by qualified professionals using **original spare parts** only.

DEVICE INSTALLATION

1. Use the key to open the housing at the top as instructed.
2. Use a screwdriver to loosen the screws inside the dispenser and remove the wall bracket.
3. As shown in Figure 2, drill two holes with a diameter of 6 mm and fasten the wall bracket using the wall plugs and screws.
4. Attach the dispenser to the wall bracket and tighten the screws inside the dispenser.

Note:
The screws must be tightened securely, and the rubber ring must be correctly fitted.
Otherwise, liquid may leak through the rubber ring.



STRUCTURE AND COMPONENTS



INITIAL START-UP

Before first use:

Unpack the appliance, check it for completeness, and set it up (see *Installation*). Clean the appliance (see *Cleaning*).

CLEANING

Wipe the exterior surfaces with a damp, soft cloth.
A mild dishwashing detergent may be used.
Wipe again with clean water (without detergent) and then dry thoroughly.
Do not use harsh, bleaching, caustic, or abrasive cleaning agents or tools, as they may damage or scratch the surfaces.


TAKING DEVICE OUT OF OPERATION / STORAGE / TRANSPORT

Clean the device thoroughly inside and outside.
If it is dry and will not be used for an extended period, store it in a dry, dust-free, and cool place. Use the original packaging to protect the device from damage.
When storing only the packaging materials, please note that components such as plastic bags, cardboard, and Styrofoam parts can be dangerous for children if they play with them unsupervised (e.g., risk of suffocation).
For transportation of the device, it is best to use the original packaging to ensure optimal protection against impact, sharp edges, and weather conditions.

TROUBLESHOOTING

Problem	Cause and Solution
No soap comes out of the outlet	The soap outlet is blocked. Clean the soap outlet.
If the problems cannot be solved through simple troubleshooting, please contact your dealer	

EXPLODED VIEW



EXPLODED VIEW: LEGEND

1	Button	Knopftaste
2	Button holder	Aufnahme für die Knopftaste
3	Push rod cover	Abdeckung für Betätigungsstange
4	Spring	Feder
5	Valve	Ventil
6	Push rod	Betätigungsstange
7	Screw joint	Verschraubung
8	Seal ring	Dichtungsring
9	Washer	Unterlegscheibe
10	Push rod bottom	Betätigungsstangeboden
11	Spring	Feder
12	Valve plug	Ventilkugelaufnahme
13	Glass ball	Glaskugel
14	Pump	Pumpe
15	Seal ring	Dichtungsring
16	Mounting board	Aufnahmeplatte
17	Screw	Schraube
18	Hanging board	Hängestück zu Aufnahmeplatte
19	Housing backwall	Gehäuse Rückwand
20	Seal ring	Dicthungsring
21	Screw	Schraube
22	Key	Schlüssel
23	Door	Tür
24	Housing	Gehäuse
25	Seal	Dichtung
26	Window	Schaufenster

PACKAGING DISPOSAL



Please separate the packaging materials accordingly and take them to the appropriate collection points for recycling and environmental protection.

DEVICE DISPOSAL



Your local authority can provide information on the locations and opening hours of disposal sites. This is the only way to ensure that old appliances are disposed of and recycled correctly.
Thank you!

Made in P.R.C for:
SARO Gastro-Products GmbH
Sandbahn 6, 46446 Emmerich am Rhein, Germany
Tel. +49 (0) 2822 9258-0
Fax +49 (0) 2822 18192
E-Mail info@saro.de
Web www.saro.de

Note: Technical, design, and model changes as well as errors are subject to change without notice.